



**EXPLODE OF HT600F**

## SPARE PARTS LIST OF HT600F

NO	CODE	NAME	MODEL	QTY	MATERIAL	REMARK
01	HT200R.01	UP HINGE COVER		1PC		
02	HT200R.02	UP HINGE		1PC		
03	HT200R.10	BUSHING		2PCS		
04	HT200R.03	THERMOSTAT	ECS-10HT1	1PC		
05	HF600.06	GASKET	1692*747	1PC		
06	HT600R.01	DOOR		1PC		
07	HF600.19	HINGE AXIS	Φ7	1PC		
08	HF600.08	DOWN HINGE		2PCS		
09	HF600.13	EVAPORATOR SUPPORT		6PCS		
10	HF600.10	EVAPORATOR		1PC		
11	S900.13	FEET		2PCS		
12	HT600F.01	BODY		1PC		
13	HT200RG.01	LOCK		1PC		
15	HT200RG.02	LOCK SUPPORT		1PC		
16	S900.47	PLUG		1PC		
17	HT200R.06	CONTROL BOX		1PC		
18	HT600F.02	COMPRESSOR	HY90Y	1PC		
19	S900.34	CONDENSER FAN	SA1238A2	1PC		
20	HF600.12	UNITE BOARD		1PC		
21	VRX.20	FAN SUPPORT		1PC		
22	HF600.17	CONDENSER		1PC		
23	AB600F.02	UNITE ROOM GRILLS		1PC		
24	HF600.14	EVAPORATOR FIXER		7PAIRS		
25	S900.32	SENSOR		1PC		
26	HT600R.03	TOP COVER		1PC		
27	HT200R.08	PLASTIC CAP		3PCS		
28	HT300R.01	HANDLE		1PC		