



RIF.	CODICE	R.C.	DENOMINAZIONE	DESCRIPTION	BESCHREIBUNG	DESIGNATION	DENOMINACIONES
1	29/99901029	*	MANOPOLA FORNO ELETTRICO	KNOB FOR ELECTRIC OVEN	KNEBEL FÜR ELEKTROHOFEN	POIGNEE POUR FOUR ELECTRIQUE	POMO PARA HORNO ELECTRICO
2	29/99901089	*	MANOPOLA FORNO 0-1-2-3	OVEN KNOB 0-1-2-3	KNEBEL 0-1-2-3	POIGNEE FOUR 0-1-2-3	MANDO HORNO 0-1-2-3
3	29/99901139	*	MANOPOLA CUCINA ELETTRICA	KNOB FOR ELECTRIC COOKER	KNEBEL FÜR ELEKTRISCHE HERD	POIGNEE POUR CUISINIERE ELECTRIQUE	POMO PARA COCINA ELECTRICA
4	14/99901620		SPIA VERDE	GREEN WARNING LIGHT	GRÜNE LAMPE	LUMIERE VERTE	LUZ VERDE
5	14/99901621		SPIA ARANCIONE	ORANGE WARNING LIGHT	ORANGE LAMPE	LUMIERE ORANGE	LUZ NARANJA
6	09/99900069	*	COMMUTATORE TERMOSTATO	SWITCH	SCHALTER	COMMUTATEUR	COMMUTADOR
7	08/85900009	*	TERMOSTATO DI LAVORO	WORK THERMOSTAT	ARBEITSTHERMOSTAT	THERMOSTAT DE TRAVAIL	TERMOSTATO DE TRABAJO
7b	09/85900009	*	COMMUTATORE FORNO-TEMPERATURA	OVEN-TEMPERATURE SWITCH	UMSCHALTER OFEN-TEMPERATUR	COMMUTATEUR FOUR - TEMPERATURE	CONMUTADOR HORNO-TEMPERATURA
8	09/16520139	*	COMMUTATORE FORNO-RESISTENZE	OVEN-RESISTOR SWITCH	UMSCHALTER OFEN-RESISTOR	COMMUTATEUR FOUR - RESISTANCE	CONMUTADOR HORNO-RESISTENCIA
9	08/85900019	*	TERMOSTATO DI SICUREZZA	SAFETY THERMOSTAT	SICHERHEITSTHERMOSTAT	THERMOSTAT DE SECURITE	TERMOSTATO DE SEGURIDAD
10	07/99600019	*	RESISTENZA FORNO	OVEN RESISTOR	RESISTOR FÜR OFEN	RESISTANCE POUR LE FOUR	RESISTENCIA PARA E HORNO
11	14/99902079		PRESSACAPO PG21	FLAT FAIRLEAD PG21	KABELDURCHFÜHRUNG PG21	PASSE-CABLE PG21	PROTECTOR DE CABLE PG21
12	14/99900750		MORSETTIERA A 6 POLI	6 POLE TERMINAL	SECHSPOLIGER KLEMMENBRETT	TERMINALE 6 POLES	TERMINAL DE CONEXION 6 POLOS
13	23/99900800		GRIGLIA SCARICO FUMI	FLUE GRILL	ABGASGITTER	GRILLE FUMEE	REJILLA SALIDA HUMOS
14	07/99600049	*	PIASTRA ELETTRICA	ELECTRIC PLATE	ELEKTRISCHE PLATTE	PLAQUE DE CUISSON ELECTRIQUE	PLACA DE COCCION ELECTRICA
15	WD/99603819		PIANO SUPERIORE	TOP	OBERE FLÄCHE	PLATEAU	PLANO SUPERIOR
16	29/99600212		GUARNIZIONE PORTA FORNO	BLACK SILICONE GASKET FOR OVEN	SCHWARZ SILIKON DICHTUNG FÜR OFEN	JOINT EN SILICONE NOIR POUR FOUR	JUNTA PARA EL HORNO
17	68/99600030		GUIDA GRIGLIA FORNO	OVEN GRID GUIDE	OFENGRILL GUIDE	GUIDE POUR LA GRILLE DU FOUR	GUIA PARA LA PARILLA DEL HORNO
18	21/GX2/1		GRIGLIA CROMATA FORNO GN 2/1	CHROMED GRID GN 2/1	VERCHROMTE GITTER GN 2/1	GRILLE CHROMEE GN 2/1	PARILLA CROMADA GN 2/1
19	15/99600140		PLATEA ANTERIORE PER CUCINE ELETTRICHE A 4 ZONE COTTURA CON FORNO	FRONT PLATE FOR 4 ZONE ELECTRIC RANGES WITH OVEN	VORDERE PLATTE FÜR 4 ZONEN-ELEKTRISCHE HERD MIT OFEN	SOUBASSEMENT ANTERIEUR POUR CUISINIERS ELECTRIQUES A 4 ZONES DE CUISSON AVEC FOUR	PLACA FONDO ANTERIOR PARA COCINAS ELECTRICAS 4 ZONAS DE COCCION CON HORNO
20	15/99600150		PLATEA POSTERIORE PER CUCINE ELETTRICHE A 4 ZONE COTTURA CON FORNO	REAR PLATE FOR 4 ZONE ELECTRIC RANGES WITH OVEN	HINTERE PLATTE FÜR 4 ZONEN-ELEKTRISCHE HERD MIT OFEN	SOUBASSEMENT POSTERIEUR POUR CUISINIERS ELECTRIQUES A 4 ZONES DE CUISSON AVEC FOUR	PLACA FONDO TRASERA PARA COCINAS ELECTRICAS 4 ZONAS DE COCCION CON HORNO
21	80-R0000810		PIASTRA PORTARULLINO	ROLL HOLDING PLATE	ROLLHALTERPLATTE	PLAQUE INSTALLATION PORTE-ROLLER	PLACA PORTA RODILLO

