

## SPARE PARTS LIST GF-6

NO.	Name	REF L2G
1	Cover plate	
2	Heating pipe partition	
3	Heating tube layering	
4	Handle fixing plate	
5	Φ25 POM stick	GF-6-5
6	Probe clip plate	
7	Oil box (small)	GF-6-7
8	Insulation cotton fixing plate	
9	Oil box (big)	GF-6-9
10	Housing	
11	Bottom plate	
12	Timer	GF-6-12
13	Indicator light (yellow)	GF-6-13
14	Indicator light (green)	GF-6-14
15	Switch	GF-6-15
16	Knob	GF-6-16
17	Thermostat	GF-6-17
18	Insulation cotton	
19	Heating element (upper)	GF-6-19
20	Tube	
21	Waffle plate (upper)	
22	Waffle plate (bottom)	
23	Copper tube	
24	Heating element (bottom)	GF-6-24
25	Cut out	GF-6-25
26	Ceramic terminal block	GF-6-26
27	Power cord	GF-6-27
28	Cable	GF-6-28
29	Rubber feet	GF-6-29
30	Screw	

