



**MODE D'EMPLOI :
TIMER ELECTRONIQUE
M4739**

Pour assurer une utilisation correcte de cet appareil et votre sécurité, veuillez lire attentivement les instructions suivantes avant d'utiliser cet appareil.

Fonctions


Minuteur – chronomètre

Décompte 29 heures 59 minutes 59 secondes

Pile CR2032 x1

Aimant au dos

Produit



Utilisation

Après avoir inséré la pile, l'écran affiche l'ensemble des informations pendant 3 secondes puis une sonnerie retentit.

Minuteur

Appuyer sur « H » pour ajouter des heures, sur « M » pour ajouter des minutes et sur « S » pour ajouter des secondes. Maintenir appuyé l'une de ces trois touches pour accélérer l'ajout des heures ou minutes. Appuyer sur « START/STOP » pour démarrer le comptage. Une alarme sonnera pendant 1 min à la fin du décompte.

Appuyer sur « START/STOP » pour reprendre le décompte.

Chronomètre

L'écran affiche « 00:00 », appuyer sur « START/STOP » pour déclencher le décompte.

Appuyer sur « START/STOP » ou n'importe quel autre bouton pour mettre sur pause.

Appuyer sur « START/STOP » pour reprendre le décompte.

Appuyer sur « START/STOP » pensant 3 secondes pour réinitialiser.

Une alarme sonnera pendant 1 min à la fin du décompte.

Functions


Timer – Stopwatch

Maximum count 23 hours and 59 minutes 59 seconds count up and down

Battery CR2032 x1

Magnet on the back

Product



Functional description

Countdown timer mode

After inserting the battery, the LCD will display all the information on screen for 3 seconds followed by a buzzer sound.

Press H to increase hours, hold it to fast increase.

Press M to increase minutes, hold it to fast increase.

Press S to increase seconds, hold it to fast increase.

Press START/STOP to start count down.

When the countdown is finished, the alarm will ring for 1 minute.

During the countdown, press any button to pause, then press START/STOP to continue.

Hold START/STOP button for 3 seconds to reset the value

Count up time

When the LCD display “00:00”, press START/STOP to count up.

Press START/STOP or any button to pause the count up. Press the button START/STOP to start again.

Hold START/STOP button for 3 seconds to reset the value.

When the count up is finished, the alarm will ring for 1 minute.



CE