

FC-LT160AH_Spare parts list**Part 1**

No.	Ref. Code	Parts name	QTY	Unit	
1	SC160-1	Canopy	1	pc	
2		Canopy perspex cover	1	pc	
3	SC160-3	Left glass door	1	pc	
4	SC160-4	Right glass door	2	pc	
5	SC160-5	Door seal	3	pc	
6	SC160-6	Door handle	1	pc	
7	SC160-7	Front grill	1	pc	
8	SC160-8	K clip	53	pc	
9	SC160-9	Shelf A	8	pc	
10	SC160-10	Shelf B	4	pc	
11	SC160-11	Back ventilation cover right	1	pc	
12	SC160-12	Back ventilation cover left	1	pc	
13	SC160-13	Castor without brake	4	pc	
14	SC160-14	Castor with brake	4	pc	

Part 2

No.	Ref. Code	Parts name	QTY	Unit	
1	SC160-2-1	Conopy box light	1	pc	
2	SC160-2-2	light switch	1	pc	
3	SC160-2-3	led light right	1	pc	
4	SC160-2-4	led light left	1	pc	
5	SC160-2-5	Middle mullion light	2	pc	
6	SC160-2-6	Terminal box	1	set	
7	SC160-2-7	Led driver	1	pc	
8	SC160-2-8	Defrost timer	1	pc	
9	SC160-2-9	Power cable	1	pc	

Part 3

No.	Ref. Code	Parts name	QTY	Unit	
1	SC160-3-1	Evaporator	1	pc	
2	SC160-3-2	Evaporator fan motor	2	pc	
3	SC160-3-3	Evaporator fan motor bracket	8	pc	
4	SC160-3-4	Fan blade	2	pc	
5	SC160-3-5	Evaporator fan motor panel	1	pc	
6	SC160-3-6	Evaporator fan motor cover	2	pc	
7	SC160-3-7	Digital controller	1	pc	

FC-LT160AH_Spare parts list					
8	SC160-3-8		1	pc	
9	SC160-3-9	Nut	1	pc	
10	SC160-3-10	Drainage mouth	1	pc	
11	SC160-3-11	Dry fliter	1	pc	
12	SC160-3-12	Water tray	1	pc	
13	SC160-3-13	Compressor	1	set	
14	SC160-3-14	Condenser fan motor bracket	2	pc	
15	SC160-3-15	Condenser fan motor	2	pc	
16	SC160-3-16	Fan blade	2	pc	
17	SC160-3-17	Condenser	2	pc	

Remarks:

Due to the continous improvements of products, the technical parameters/spare parts will be modified without prior notice.