

## **BEVERAGE COOLER**





## **INDEX**

General information	3
General use	3
Technical data	
Installation and maintenance	
Trouble shooting	5
Exploded view and spare parts list	
Wiring diagram	8
Standards and directives	
Packaging and device disposal	



#### **GENERAL INFORMATION**

The purpose of this document is to provide important information regarding the installation, use and maintenance of the cooler.

Before any operation, you should read carefully the information contained in this manual.

The manufacturer assumes no liability for parts or labour coverage for component failure or other damages resulting from improper usage, installation or failure to clean and / or maintain product as set forth in these instructions.

#### **GENERAL USE**



# The cooler is not designed for external (outdoor) placement or environments that subject it to the actions of atmospheric agents (rain, direct sun light)

The manufacturer is not responsible for damages resulting from the improper use of the product.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING: Do not damage the refrigerant circuit.
- WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

Do not Store explosive substances such as aerosol cans with a flammable propellant in this appliance.

#### **TESTING**

The cooler is shipped ready for use.

The temperature control is preset from the factory.

As needed, the temperature control can be adjusted Clock-wise to make the product "Colder", the control can be adjusted Counter Clockwise to make the product "Warmer"

#### RESPONSIBILITY OF THE CUSTOMER

Ensure that the electrical outlet is connected effectively to earth (ground), suitable to provide the voltage indicated on the data plate.

Make sure that the cooler is placed on a level surface.

### **TECHNICAL DATA**

Modele	Voltage (V)	Power (W)	Porduct Dimension (mm)	Package (mm)
VBC125C	220-240V/50Hz	115W	403*455*1905mm	450*495*1980mm

## **MATERIALS AND REFRIGERANTS**

Interior or exterior surfaces that come into contact with the product are made of galvanized steel, aluminium or non-toxic plastic materials. The refrigerant used is approved by government regulations.

The type and quantity of the gas charged, in the refrigeration unit, is indicated on the data plate.



#### INSTALLATION

For safe proper operation, follow the manufacturers instructions reported in this section.

#### **POSITIONING**

The cooler must be placed in an adequately ventilated room. Keep away from heat sources, such as radiators or air conditioning pipes. Allow free air circulation to the refrigerator unit.

The ambient temperature must not be higher than 30°C.

This appliance climate class is 4,5

Test room climate class	Dry bulb temperature °C	Relative humidity %	Dew point °C	Water weight in dry air g/kg
0	20	50	9.3	7.3
1	16	80	12.6	9.1
2	22	65	15.2	10.8
3	25	60	16.7	12
4	30	55	20	14.8
5	40	40	23.9	18.8
6	27	70	21	15.8
7	35	75	30	27.3

Note: The maximum of shelf loading capacity is 13 Kg.

Cooler Levelling: To provide the best performance the cooler must remain level.

#### **ELECTRICAL CONNECTION**

#### **WARNING DO NOT USE EXTENSION CORDS**

The cooler works on single-phase voltage (220-240V/50Hz) power supply. To switch on the cooler, insert the plug into the outlet, Ensure that:

The electrical outlet must be provided with an efficient ground, the voltage and the frequency of the electrical line matches those indicated on the data plate. If unsure about the efficiency of the ground, have your electrical circuit checked by qualified technician.

When the cooler is operating, check that the supply voltage is not dropping or increasing under/over +10% the rated voltage (187 Volts to 242Volts) If the light is damaged, it must be replaced with a same size, power and shape one. and must be replaced by the manufacturer or its service agent

The manufacturer is not responsible for damages or accidents arising from the misuse or disregard of electrical laws relevant to the country where the cooler is used.

If LED lights broken down, maintaince should be done by supplier.

### **MAINTENANCE**

- Before cleaning the cooler always remember to unplug it.
- Unplug the cooler at the electrical outlet; never pull the service cord.
- Do not use sharp objects for cleaning.
- Clean the inside cabinet of cooler with a clean damp cloth or with neutral soap. Avoid damage by never using abrasive or flammable cleaning products.
- Clean the condenser at least once a month with a vacuum cleaner or a brush to eliminate the dust accumulation.
- Do not wash the cooler with direct or high pressure water jets.

# INSTRUCTION MANUAL



#### TROUBLE SHOOTING

Often problems that occur during normal operation can be resolved without the assistance of a specialized technician. Before calling the technical assistance, verify the following:


- a) The appliance does not operate.
- Check that the plug is correctly inserted into the electrical outlet.
- Verify that there is voltage at the electrical outlet
- b) The product is too warm.
- Check the setting of the thermostat. (See Testing Section)
- Check the closing of the door, and ensure door gasket seals.
- Check that the interior fan is operating, and not blocked.
- Check and clean the condenser
- c) The appliance is excessively noisy.
- -Verify the equipment is level.
- -Ensure that the equipment is not touching other equipment that could cause vibration,

#### Prepare to answer the following:

- The type of problem: (electrical, mechanical)
- The model, code and serial number of the cooler can be found on the manufacturer label attached to the interior wall of the cooler.



## **EXPLODED VIEW**






## **SPARE PARTS LIST**

Item	Parts name in English	REF L2G	QUANTITE
1	top cover		1
2	forming cabinet		1
3	upper door bushing		2
4	upper door axis		1
5	canopy left cover		1
6	switch	VBC125C-1	1
7	canopy(with switch)	VBC125C-3	1
8	canopy LED strip	VBC125C-4	1
9	canopy right cover	1001200 1	1
10	canopy panel	VBC125C-6	1
11	glass door	VBC125C-13	1
12	door seal	VBC125C-13	1
13	door LED light	VBC125C-12	2
14	down door bushing	VDC123C 12	1
15	down door axis		1
16	ventilation grill		1
17	condenser		1
18	condenser fan	VBC125C-20	1
19	compressor	VBC125C 20	1
20	fliter	VBC125C-29	1
21	power cord fixing board	VDC123C 29	1
22	front feet		1
23	feet reinforcement		1
24	compressor panel		1
25	feet		3
26	φ22 wire ring		3
27	power cord fixing clip		1
28	power cord		1
29	back cover		1
30	water drip box		1
31	main control board	VBC125C-31	1
32	evaporator silicone cap	VDC123C 31	1
33	shelf rail		4
34	shelf fixer		24
35	shelf		6
36	price tag	1	6
37	evaporating panel		1
38	evaporating panel mat	1	8
39	fan cover	<del> </del>	1
40	evaporator board	<del> </del>	1
41	wiring knob		1
42	potential device fixing board	1	1
43	sensor	VBC125C-44	1
44	thermostat tag	. 201200 11	1
45	potential device	VBC125C-45	1
46	evaporator fan	VBC125C-45 VBC125C-41	1
47	inner liner top light	VBC125C-47	1
48	back cover	1001200 41	1
49	canopy board		1
+3	carropy board	I.	



## **WIRING DIAGRAM**





#### STANDARDS AND DIRECTIVES

#### Meaning of crossed out wheeled dustbin:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

The device complies with current EU standards and directives. If necessary, we will send you the corresponding declaration of conformity.

## **Packaging disposal**

Please separate the packaging materials accordingly and return them to the responsible collection points for recycling and environmental housing.

#### **Device disposal**

once the appliance has been used up, dispose of it properly at a collection point for electrical appliances. Electrical appliances do not belong in household waste.

Your responsible administration will inform you about the addresses and opening hours of collection points. This is the only way to ensure that old appliances are properly disposed of and recycled. Thank you very much!





